



No.	Code name	Name	Qty.	No.	Code name	Name	Qty.
1	B21-01-13	FRONT SIGHT SLIDING BASE	1	37	GB/T119-1986 3×22	PIN	3
2	B21-01-14A	FRONT SIGHT	1	38	B21-04A-9A	TRIGGER BLADE	1
3	GB/T823-1988 M5×10	SCREW	1	39	B21-04A-200	TRANSMISSION BLOCK ASSEMBLY	1
4	B21-01-15	SCREW	1	40	B21-04A-14	SCREW	2
5	GB/T818-1985 M3×8	SCREW	2	41	B21-04A-8	PISTON SAER LEVER SPRING	1
6	B21-02A-00	REAR SIGHT	1	42	GB/T119-1986 5×24	PIN	1
7	B30-07-14	PULL JACKET	1	43	GB/T896-1988 4	COLLAR	1
8	B21-01-5A	JOINT COVER	1	44	B21-00-8	AXES	1
9	B21-01-4	JOINT NUT	1	45	B21-07-1	JOINT AXES COVER	1
10	B21-00-6	SCREW	1	46	B21-00-2	PISTON SPRING LEADER	1
11	B21-07-7	COUPLING	1	47	B21-00-9	NUT	1
12	B21-07-8	PIN	1	48	GB/T95-1985 14	WASHER	1
13	B21-07-9		1	49	B21-07-12		1
14	GB/T896-1986 3	COLLAR	1	50	GB/T6172-1986 M5	NUT	1
15	B21-06-00	SAFETY ASSEMBLY	1	51	B21-00-1	PISTON SPRING	1
16	B21-07-11	JOINT LEVER	1	52	B30-05-00	STOCK ASSEMBLY	1
17	B21-07-10	JOINT LEVER COVER	1	53	GB/T93-1987 6	WASHER	2
18	B30-07-3	PULL	1	54	GB/T818-1985 M6×32	SCREW	1
19	B21-04A-13	AXES	2	55	B21-00-5	ROTARY PIM	2
20	B21-04A-19	SPRING	1	56	B21-00-4	SCREW	1
21	B21-07-2A	STOP COVER	1	57	GB/T808-1988 M8×0.75	NUT	1
22	GB/T119-1986 5×30	PIN	1	58	B21-00-3	SPRING	1
23	GB/T848-1985 5	WASHER	1	59	B21-03-200	PISTON ASSEMBLY	1
24	B21-04A-100	SHOOTING BASE ASSEMBLY	1	60	B21-01-12	SCREW	1
25	B21-04A-12		2	61	B21-00-7	STOP BLOCK	1
26	B21-04A-4	STOP COVER	1	62	GB/T95-1985 6	WASHER	1
27	B21-04A-1A	SLIDING BLOCK	1	63	GB/T818-1985 M6×16	SCREW	1
28	B21-04A-5	STEEL BALL SPRING	1	64	B21-03-100A	TUBE ASSEMBLY	1
29	B21-04A-2	SLIDING SPRING	1	65	B30-01-100	BORE ASSEMBLY	1
30	GB/T308-1989 3	STEEL BALL	1	66	B21-01-7A	FRONT SIGHT	1
31	B21-04A-300	SAFETY ASSEMBLY	1	67	B21-01-16	SCREW	1
32	B21-04A-10	SAFETY LEVER	1	68	GB/T77-1985 M5×8	SCREW	1
33	B21-04A-20A	TRANSMISSION BLOCK SPRING	1	69	B21-03-1A	SEAL	1
34	B21-04A-3	CHOCK	1	70	B21-03-4	PISTON SEAL	1
35	B21-00-10	JOINT PIN	1	71	B21-05-2	TRIGGER GUARD	1
36	B21-04A-7	PISTON SEAE LEVER	1				